




Product Overview

The NEOECO E206 Tracker is a universal item finder that works with the Apple Find My network or Google's Find Hub network to help you locate your valuable items. During initial setup, you can select your preferred network. However, the finder cannot operate on both networks simultaneously. Once a network is selected, the other is automatically disabled. To switch networks, you must perform a factory reset on the finder.

Before you start

Before you start, ensure Bluetooth is enabled on your Android™ or iOS device and the device has internet access via Wi-Fi or cellular service.

Log in Find Hub App

1. Go to Google Play and search for "Find Hub".
2. Search for Find Hub on Google Play.
3. Hit "Open" or click on the Find Hub app icon on your phone homepage.
4. Log into the Find Hub app with your Google Account. You might want to select the check box that says "Don't ask again." If you have more than one account, your item will link to the primary account setup on your phone.
5. You might be asked to allow some permissions. Review the terms and continue.

NEOECO E206 Tracker Pairing Guide

Prerequisite

Ensure the finder is prepared with a suitable battery (refer to the product specification for battery model).

Pairing with iOS Device

1. Place your finder near your iOS device.
2. Insert the battery and tighten the battery cover to power on the device. If the activation is successful, you will hear a beep.
3. On your iOS device, open the Find My app. Tap the Items tab and select add item. Select Other Supported Item (If you have added items before, tap the "+" button first, then choose "Add Other Item").
4. Once the Find My app detects your finder, follow the on-screen instructions to add it to the Find My app.

Pairing with Android Device

1. Place the finder near your Android device (ensure the device is awake and unlocked). Insert the battery and tighten the battery cover to power on the device. If the activation is successful, you will hear a beep.
2. Wait for a half-screen notification to appear, then follow the on-screen instructions on your Android device to add the finder to Find Hub app.

Power on

1. Open the battery cover and put the battery inside.
2. Tighten the battery cover, the device will beep and start working.

How to Disable the NEOECO E206 Tracker

1. Twist the engraved back cover counterclockwise to open the device.
2. Remove the inner CR2032 button battery.
3. The NEOECO E206 Tracker deactivates instantly upon battery removal.

How to Re-enable the NEOECO E206 Tracker

1. Twist the engraved back cover counterclockwise to open the device.
2. Insert the CR2032 button battery, replace the cover, then rotate it clockwise to lock it.
3. Hearing the sound indicates re-enable ok.

Identification Mode Instructions

1. Flip the NEOECO E206 Tracker back and forth five times.
2. You will hear a confirmation sound.

Steps for Factory Reset

1. Rotate the battery cover counterclockwise and remove the battery.
2. Insert the battery into the device and then take it out right away.
3. Repeat step 2 five times. Two consecutive beeps indicate
4. that the factory reset has been completed successfully. At this point, the NEOECO E206 Tracker will enter pairing mode.

How to stop the device from ringing

Flip the NEOECO E206 Tracker once to turn off the ringer when it is ringing.

FQA

Device cannot be detected

1. Confirm correct battery polarity (+/- aligned) and fully tightened battery cover.
2. Keep tracker and mobile device within 10 m, with no obstacles (e.g., metal cases) in between.
3. Verify device system version: iOS 14.5+/Android 9+.

No beep after power-on

1. Replace with a new compatible battery.
2. Wipe battery contacts with a dry cloth to remove dust or oxidation.

Pairing fails halfway

1. Restart the pairing app (Find My/Find Hub) and retry.
2. Restart your mobile device and repeat pairing steps.
3. Ensure Bluetooth is enabled on the mobile device.


Disclaimers

1. Location services and Google Location Sharing must be turned on. Requires internet connection. Available on Android 9+ and in certain countries for age-eligible users.
2. Find Hub network requires location services and Bluetooth to be turned on. Requires cell service or internet connection. Works on Android 9+ and in certain countries for age-eligible users.
3. This product has been certified by Google to meet Find Hub network accessory specifications. Google is not responsible for the operation of this product. Google is also not responsible for ensuring that the product complies with any applicable safety standards or other requirements.

Replace the Battery

If the device beeps intermittently or fails to power on, Replace the battery as follows:

1. Rotate the battery cover counterclockwise and remove the old CR2032 battery.
2. Wipe the internal battery contacts with a dry cloth to remove dust or oxidation.
3. Insert a new CR2032 battery with correct polarity (+/- aligned with contacts).
4. Align the cover with the threads and rotate clockwise to lock fully. Two consecutive beeps confirm successful battery replacement and restart. The NEOECO E206 Tracker will restart the normal use.



Location & Notification Features

Locate Your Finder (Nearby)

1. Open the Find My app or Find Hub app, then tap your NEOECO E206 Tracker from the item/device list.
2. Tap "Play Sound" to make your finder beep.
3. Once you've located it, stop the beeping by the app or flip the finder once.

Locate Your Finder (Faraway)

1. Open the Find My app or Find Hub app, then tap your NEOECO E206 Tracker from the item/device list.
2. The current location of your finder will appear on the map along with the timestamp detected last time.

Enable Notify When Left Behind (Find My Only)

1. Open the Find My app and select your NEOECO E206 Tracker from the item list.
2. Under Notifications, enable the Notify When Left Behind option.
3. You will receive a notification if you leave your finder behind and it is out of the Bluetooth range of your iOS device.

Enable Notify When Found (Find Hub Only)

1. Open the Find Hub app and select your NEOECO E206 Tracker from the item list.
2. Under Notifications, turn on the toggle of Notify When Found.
3. You will receive a location notification when your finder is detected by another device on the Find Hub network.

Note: This function is only active when the finder is out of your Android device's Bluetooth range.


Mark as Lost (Find Hub Only)

1. Open the Find Hub app and select your NEOECO E206 Tracker from the item list.
2. Tap "Mark as Lost" and follow the on-screen instructions to fill the contact information.
3. You will receive a notification if the Find Hub network locates your lost E206 Tracker.

Compatibility, Legal and Credit Line

The Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, iPod touch, Mac, or the Find Items app on Apple Watch. To use the Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS. Apple, Apple Watch, Find My, iPhone, iPad, iPod touch, iPadOS, Mac, macOS, watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Find My network product specifications and requirements. Apple is not responsible for the operation of this device or of its product or its compliance with safety and regulatory standards. Find Hub helps you find and connect to what matters in a single, secure place. Find your belongings quickly and safely—even if your devices are offline. Plus, seamlessly and securely share your location with friends & family for peace of mind. The Find Hub network requires location services and Bluetooth to be turned on.

Google, Android, Google Play and Find Hub are trademarks of Google LLC.



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Made in China